

Digital Pail Heater Instruction Manual



54 Elizabeth Street, Building #10
Red Hook NY 12571

Order Line: (866) 468-8473

Tech Line: (845) 758-0700

Fax: (845) 758-2057

Cautions and warnings

Although this Pail Heater is designed for outdoor operation, as with all electrical devices there is a risk of electric shock which can result in injury or death. Be sure the plug connection is not in standing water.

DO NOT use the Pail Heater if there are any visible signs of damage.

This product is intended for the heating of pails drums, no other use is approved.

Bunching, folding or over-lapping heated areas of the Pail Heater will result in over-heating. This can result in damage to the Pail Heater. Read the section on How to Install for specific information.

ONLY use the proper sized pail, the heated area should NOT over-lap.

Be sure to use the proper electrical voltage as your power supply

How to Install

1. Fit the Pail Heater around the drum and draw as snug as possible to ensure the best contact with the drum surface as possible. Attach via the Velcro closures.
2. Once properly installed energize the Pail Heater by plugging it into the proper power supply.
3. Set the Digital Thermostat to the desired temperature.

SETTING THE DESIRED TEMPERATURE (SETPOINT)

To view and adjust the set point, follow these steps:

Allow the controller to go through the start up procedure (about 10 seconds). Then press and hold the MENU button until the display changes to flashing SP.

Press the MENU button again. The current set point is displayed.

Press the Up or Down button to adjust the set point temperature (max. 212 Fahrenheit or 100 Celsius).

Press the MENU button to save.

The display then returns to the sensor reading temperature (Process Value)

The Digital Control is set at the at the time of manufacture to a setting of 135F. To convert to Celsius, press the Up and Down buttons simultaneously. Press them again simultaneously to return to Fahrenheit.

The Drum Heater has a NEMA4X (water tight) high-impact plastic enclosure. It does not require any additional internal wiring, it is pre-wired.

High voltages may be present at AMP electrical terminals and other exposed internal metal surfaces. DO NOT open the Digital Controller for any reason, high voltage is present inside the case, no repairs will be possible outside the Factory. Should a malfunction occur, the entire unit needs to be returned to be evaluated/repaired.

SETTING OTHER FUNCTIONS

It is not recommended to change Factory Settings of other functions since it will cause significantly lesser accuracy of controlling of a given set point.

These other functions are:

Differential - displayed on the LCD as diF (factory setting "1")

Anti-short Cycle Delay - displayed on the LCD as ASd (factory setting "0")

Temperature Offset - displayed on the LCD as OFS (factory setting "0")

Sensor Failure Operation- displayed on the LCD as SF (factory setting "0")

Press and hold the MENU button until the display changes to flashing SP. This will take about 2 seconds.

Press the Up or Down button repeatedly until the desired function is displayed.
(SP,dIF,Asd,OFS,SF)

Press the MENU button to display the function's current value

Press Up or Down button until desired value is displayed.

Press the MENU button to save the new value. The display then returns to the sensor temperature.

How to Store

CHR Pail Heaters are built tough to handle life in the field, however if cared for they will last longer. We suggest the life expectancy of the product to be 5 years or more, but have seen many last much longer!

Store the Pail Heaters flat or rolled up loosely, but try not to fold over and make hard crease.

Do NOT crush the Pail Heaters placing something heavy on top of them

Troubleshooting

SIZING PROBLEMS

TOO SHORT Should the Pail Heater not reach all the way around- remove completely and re-install making sure that the Pail Heater is flat and smooth.

TOO LONG Check to see if the heated areas of the warmer overlap each other; if the heated areas overlap, it is not the proper size for the pail.

Should the Pail Heater be too long it should NOT be used.

ELECTRICAL / HEATING PROBLEMS

NOT HOT ENOUGH: If the Pail Heater seems not be getting hot enough, check it with an infrared temperature sensor. If it is determined to be operating low, try to ensure that the adequate Amps or Watts are available and that voltage is correct. If less than proper Voltage is (i.e.: 120 or 240 depending on model) the warmers will operate at less than their potential. Extra long extension cords should not be used, whereas voltage will drop over the length of the cord. A proper heavy duty extension cord should be used.

TOO HOT: If it is thought the heater is too hot, check with infrared temperature sensor. If it is determined that it is actually running too hot send the Pail Heater in to us for calibration or repair.

POWER CORD PULLED OUT: This should ONLY be done by a CHR technician. More damage is usually done by someone trying to make a "quick-fix".

MELTED THROUGH: If the Pail Heater is melted, this is a sign of either improper installation or a malfunction with the heater and should be taken seriously.

You should not use the Pail Heater at all until it can be checked by a technician at CHR Inc.

Warranty Information

All CHR products come with one year warranty from date of purchase.

Warranty cards MUST be filled out and sent in to our physical address within 30 days of purchase.

CHR will, at their option, repair or replace defective products free of charge during the warranty period, including standard UPS shipping within the USA to the customer. This includes ANY flaw during the manufacturing process including normal heat-up, temperature accuracy or failure.

The warranty only excludes mis-use or abuse to the product, such as:

- Leaving the Pail Heater plugged in or energized while NOT mounted on a pail.
- Bunching or folding the Pail Heater over during operation.
- Using on the incorrect pail size, over-lapping the Pail Heater.
- Stepping on, driving over or crushing the Pail Heater.

REPAIRS AND WARRANTY CLAIMS

The physical address of CHR is:

54 Elizabeth Street, #10
Red Hook, NY 12571

Warmers should be sent via UPS or Federal Express and have the following information included in the box:

Name:

Date:

Mailing Address:

Day-time telephone:

Problem or symptom:

Date product is needed back (we will make best efforts):

Method of payment: Credit Card or COD

WARRANTY CARD:

Fill both out and return to our office,
54 Elizabeth Street, Building #10, Red Hook NY 12571

PRINT LEGIBLY OR TYPE

NAME: _____

DATE: _____

ADDRESS: _____

MODEL: _____

SERIAL NUMBER: _____ (located on power-cord)

PURCHASED FROM: _____